

# **PROVOZNÍ ŘÁD GRILOVIŠTĚ INSTRUKCE K OVLÁDÁNÍ A ČIŠTĚNÍ GRILU**

## **OPERATING RULES FOR THE BBQ AREA INSTRUCTIONS FOR OPERATING AND CLEANING THE GRILL**

### **Ovládání grilu**

- Sejměte příkrytí griloviště
- Otevřete přívod plynu z plynové lahve
- Gril má tři hořáky a tři ovládací kolečka, otočením a nastavením intenzity tepla zvolte grilovací plochu – optimální teplota je 230-250 C
- **!! POKLOP MUSÍ BÝT STÁLE OTEVŘEN !!**
- Pokud potřebujete grilované pokrmy přiklopit použijte k tomu určené nádoby
- Teplotu vidíte na teploměru

### **Čištění grilu**

- Hrubé nečistoty seškrábejte lopatkou do rohu, kde je otvor a sběrná nádoba
- Gril vypněte a nechte ca. 5 min. vychladnout a následně nalijte trochu vody
- Při odpaření vody seškrábněte nečistoty kartáčem do otvoru sběrné nádoby
- Otřete plotnu do čista papírovou utěrkou
- Ujistěte se, že je gril vypnutý a vychladlý
- Zavřete přívod plynu z lahve
- Zavřete poklop grilu a přikryjte griloviště

### **Provozní řád griloviště**

- Piknikové místo je možné používat denně od 10:00 do 22:00 hodin
- Grilovat je dovoleno pouze na plynovém grilu, který je součástí piknikového místa

- Grilovat je dovoleno pouze osobám starším 18 let, osobám mladším 18 let pouze pod dohledem dospělých
- Před použitím grilu je nutné se seznámit s jeho obsluhou na informační ceduli
- Při obsluze grilu postupujte dle návodu k obsluze umístěného na ceduli
- Pokud se setkáte s poškozením zeleně nebo vybavení, oznamte to prosím neprodleně na tel. čísle majitele objektu
- Nezanedbávejte v okolí žádné odpadky
- Po použití grilu očistěte nerezové plotny od nečistot a připečeného tuku

### **Je zakázáno**

- Poškozovat a znečišťovat prostor zařízení a vybavení
- Rozdělávání a udržování otevřených ohňů

### **Uživatel je povinen**

- Respektovat provozní řád a pokyny správce
- Neohrožovat sebe ani ostatní uživatele
- Dodržovat čistotu a pořádek, zabránit poškození griloviště a piknikového místa
- Po grilování očistit grilovací plotnu
- Zdržet se nadměrné hlučnosti
- Dbát zvýšené opatrnosti – hrozí riziko popálení

### **Důležitá telefonní čísla**

150 Hasiči

155 Záchraná služba

158 Policie

112 Tísňové volání

## **Grill Operation**

1. Remove the grill cover.
2. Open the gas supply from the gas bottle.
3. Turn on the grill:
  - o The grill has 3 burners and 3 control knobs.
  - o Turn the knobs to ignite the burners and adjust the heat intensity.
  - o The recommended grilling temperature is 230–250 °C.
4. !!! The grill lid must remain open at all times during use !!!
  - o If you need to cover the food while grilling, use suitable cookware with a lid.
5. Check the temperature on the built-in thermometer.

## **Grill Cleaning**

1. Scrape off coarse residues into the corner where the opening and the collection tray are located.
2. Turn off the grill and let it cool down for approximately 5 minutes, then pour in a little water.
3. As the water evaporates, scrape off remaining residues into the opening and collection tray using a brush.
4. Wipe the surface clean with a paper towel.
5. Make sure the grill is turned off and has cooled down.
6. Close the gas supply from the bottle.
7. Close the grill lid and cover the grill station.

## **Grill Site Operating Rules**

- The picnic area is available daily from 10:00 AM to 10:00 PM.
- Grilling is only allowed on the gas grill provided at the picnic site.

- Only persons 18 years or older may use the grill; minors must be supervised by an adult.
- Before using the grill, please read the operating instructions on the information board.
- Always follow the grill operation instructions provided on the sign.
- If you witness any damage to the greenery around you or equipment, please report it immediately to the property owner's phone number.
- Do not leave any litter in the area.
- After using the grill, clean the stainless steel surface of any residues and burnt fat and oils.

### **Not Allowed**

- Damaging or polluting the area, facilities, or equipment.
- Starting or maintaining open fires.

### **User Responsibilities**

- Follow the operating rules and comply with instructions from the site manager.
- Do not put yourself or others in danger.
- Maintain cleanliness and order, and prevent any damage to the grill or picnic area.
- Clean the grill plate after use.
- Avoid excessive noise.
- Exercise increased caution – there is a risk of burns.

### **Emergency Numbers**

150 – Fire Department

155 – Emergency Medical Services/Ambulance Service

158 – Police

112 – General Emergency Number